




EXTREME PLUS BAER 6MB, 15.0



Measure hub center of the wheel, select corresponding size and cut out accordingly.

Use a ruler to see if the fax has **ENLARGED** or **reduced** the scale.

